



To the solenoid coil type NG6 HK DHI

Corresponding connectors

HKSP664, HKSP666, HKSP667, HKSP668,
 HKSP669 (rectifier plug)

| Name | Napięcie | Odpowiednia wtyczka | Typ zaworu | Średni pobór mocy [W] | Średni pobór prądu [A] |
|------------------|----------------|-----------------------------|------------|-----------------------|------------------------|
| HK SP COU 12 DC | 12V DC | 664, 666, 667, 668 | HK DHI | 33 | 2,80 |
| HK SP COU 24 DC | 24V DC | 664, 666, 667, 668 | HK DHI | 33 | 1,40 |
| HK SP COU 28DC | 28V DC mobilne | 664, 666, 667, 668 | HK DHI | 35 | 1,24 |
| HK SP COI 110 AC | 110V 50Hz AC | 664, 666, 667, 668 | HK DHI | 60 | 0,50 |
| HK SP COI 230 AC | 230V 50Hz AC | 664, 666, 667, 668 | HK DHI | 60 | 0,25 |
| HK SP COU 230 RC | 230V 50Hz RC | 669 (wtyczka prostownikowa) | HK DHI | 40 | 0,25 |
| HK SPCOE 12 DC | 12V DC | 664, 666, 667, 668 | HK DHE | 30 | 2,80 |
| HK SPCOE 24 DC | 24V DC | 664, 666, 667, 668 | HK DHE | 30 | 1,40 |
| HK SPCOE 28 DC | 28V DC mobilne | 664, 666, 667, 668 | HK DHE | 30 | 1,24 |
| HK SPCOER 110 AC | 110V 50Hz AC | 664, 666, 667, 668 | HK DHER | 30 | 0,50 |
| HK SPCOER 230AC | 230V 50Hz AC | 664, 666, 667, 668 | HK DHER | 30 | 0,25 |