



To the solenoid coil type NG6 HK DHI

Corresponding connectors

HKSP664, HKSP666, HKSP667, HKSP668,
 HKSP669 (rectifier plug)

Name	Napięcie	Odpowiednia wtyczka	Typ zaworu	Średni pobór mocy [W]	Średni pobór prądu [A]
HK SP COU 12 DC	12V DC	664, 666, 667, 668	HK DHI	33	2,80
HK SP COU 24 DC	24V DC	664, 666, 667, 668	HK DHI	33	1,40
HK SP COU 28DC	28V DC mobilne	664, 666, 667, 668	HK DHI	35	1,24
HK SP COI 110 AC	110V 50Hz AC	664, 666, 667, 668	HK DHI	60	0,50
HK SP COI 230 AC	230V 50Hz AC	664, 666, 667, 668	HK DHI	60	0,25
HK SP COU 230 RC	230V 50Hz RC	669 (wtyczka prostownikowa)	HK DHI	40	0,25
HK SPCOE 12 DC	12V DC	664, 666, 667, 668	HK DHE	30	2,80
HK SPCOE 24 DC	24V DC	664, 666, 667, 668	HK DHE	30	1,40
HK SPCOE 28 DC	28V DC mobilne	664, 666, 667, 668	HK DHE	30	1,24
HK SPCOER 110 AC	110V 50Hz AC	664, 666, 667, 668	HK DHER	30	0,50
HK SPCOER 230AC	230V 50Hz AC	664, 666, 667, 668	HK DHER	30	0,25